



379 710



379 711



379 708



379 707

ORDER INFORMATION

| Part no. | Description | Service manual |
|---|--|----------------|
| EvacuMaster WASTE OIL SUCTION UNIT Includes 8 pc wand kit 737 950 | | |
| 379 711 | Wall mounted waste oil suction unit | SM837822 |
| 379 710 | Pedestal mounted waste oil suction unit | |
| EvacuMaster WASTE OIL PORTABLE UNIT Includes 8 pc wand kit 737 950 | | |
| 379 707 | EvacuMaster Portable: A portable version of our single point used fluid suction unit | SM837822 |
| 379 708 | EvacuMaster Portable: with drain bowl | |



Recommended Accessories

| | | |
|--|-----------------|--|
| | 506 503 | 20' x 5/8" HP Waste Oil Suction - Steel Shaft & Swivel 2,000 psi |
| | 737 950 | Wand and adaptor kit for use with all waste oil suction units. |
| | 737 952 | Flex-0.23 x 0.15 x 27.55" |
| | 737 953 | Flex-0.31 x 0.23 x 27.55" |
| | 737 960 - qty 2 | Flex-0.19 x 0.15 x 27.55" |
| | 737 958 | Flex-0.23 x 0.15 x 47.24" |
| | 737 959 | Flex-0.31 x 0.23 x 47.24" |
| | 737 961 - qty 2 | Flex-0.23 x 0.15 x 27.55" |